Meet your new phone

xfinity mobile

SAMSUNG
Galaxy S8 | S8+

A map of the hardware


Rear
camera
Fingerprint
scanner
Flash
SAMSUNG

Edge screen functions

Use the edge screens for fast & easy access to people, information and apps.

From the Home screen, swipe up for **Apps** and then tap **Settings** > **Display** > **Edge screen**.



Swipe to view edge screen. Drag a notification for more details.

Apps edge
Create shortcuts to access frequently used apps.

People edge
See notifications of missed calls and messages from your important contacts.

Smart select
Capture images and GIF animations.

Hello Bixby

To launch **Hello Bixby**, press the **Bixby** key.

Hello Bixby allows you to quickly set reminders, create voice dictation, search and access content on your phone and on the Internet.



Steps to phone setup

Charge up

Included here you'll find an Adaptive Fast Charger and USB cable. Connect them to each other, and then to your phone. Plug it in until your phone reaches 100%.



WARNING: Use only Samsung-approved charging devices. Samsung accessories are designed to maximize battery life. Using other accessories may invalidate your warranty and may cause damage.

Activate!

Before turning on your phone, activation is essential. On another device, pull up this site: **xfinitymobile.com/activate**. Log in and you'll be stepped right through the process.

microSD/SIM Card Tray

If you have a microSD Card, insert it here:



NOTE: To access the microSD Card slot, remove the microSD/SIM Card tray from the device.

The how-to basics

Powering on and off

To turn your phone on, press and hold the power/lock button. Once it's on, press and hold that same button to power it off.



The screen basics

To turn on your screen, press the power/lock button, then swipe up onscreen to unlock it. To turn your screen off, just press the power/lock button.



The XFINITY Mobile app

The XFINITY Mobile app is preloaded on your phone. Consider it your control center to track your usage, manage your account and ask anything.



Voicemail 101

The Voicemail app is preloaded on your phone. You can use it to listen to your messages or read them as text and record a custom greeting.



Questions?
Dial our support line: 1 (888) 936-4968

Copyright 2017 Samsung Electronics Company, Ltd. Samsung, Galaxy S, and Samsung Pay, are trademarks of Samsung Electronics Co., Ltd. Android, Google, the Google Logo and Google Play are trademarks of Google Inc. Screen images simulated. Appearance of device may vary.
The XFINITY Mobile logo and the New Network mark ("O") are trademarks of Comcast. All rights reserved.

BC Printed in Korea. GH68-47464E